


HANDY TOOLBOX



Materials

- 2 pieces 1 x 6 (actual 3/4" x 5 1/2") x 10 1/2" white pine (ends)
- 1 piece 1 x 6 (actual 3/4" x 5 1/2") x 13 1/2" white pine (base)
- 2 pieces 1 x 6 (actual 3/4" x 5 1/2") x 15" white pine (sides)
- 1 piece 3/4" Dowel Stock 15" long (handle)
- 2" finishing nails (60)
- Sandpaper (medium and fine grit)
- Glue
- Finishing material (natural or painted)

Tools Needed


- Square
- Saw (crosscut)
- Boring tool with 3/4" bit
- Hammer

Instructions

1. Using the template as a guide mark off and cut the taper ends on the 2 pieces of 1 x 6 (actual 3/4" x 5 1/2") x 10 1/2".
2. Using a square set off the center for the handle holes in each end piece. They are located 1 1/2" down from top and centered. Drill 3/4" holes at this location for the handle.
3. Assemble the ends to the base by putting about 3 nails in each end.
4. Assemble the sides to the ends and base by putting about 3 nails on each end of the sides. Put 3 or 4 nails along the sides into the base.
5. Apply glue sparingly to the inside of 3/4" holes on each end piece and insert the 3/4" x 15" dowel. Remove any excess glue with damp cloth.
6. Sand all parts so they are smooth for appropriate finish.
7. Finish the tool box with either a natural or painted finish.

*Adapted from plans by Wayne Torgersen

1/2
b/w



BORE $\frac{3}{4}$ " DIA. HOLE

END TEMPLATE